EPOS | SENNHEISER



C50

Wireless Communication Headset with ANC

User Guide

Contents

Welcome	2
Package contents	3
Product overview Overview of the headset Overview of the headset LED indications	4
Overview of the headset buttons Overview of the dongle Overview of the dongle LED indications Overview of the dongle button	6 6
Overview of the icons	
Pairing the headset with Bluetooth® devices Using the USB cable Installing the EPOS Connect software Changing Audio settings for the headset - Microsoft® Windows	8 9
Using the headset Turning the headset on and connecting it	
Making calls using the headset	14 15 15
Using headset and dongle with Microsoft® Teams	17
Listening to audio using the headset	18
Additional functions Charging the headset battery Verifying remaining battery power Storing and transporting the headset If you leave the Bluetooth range Reconnecting / disconnecting Bluetooth Enabling / disabling voice prompts	
Maintaining the products and updating the firmware	22 22
If a problem occurs Clearing the pairing list of the headset (Reset) Clearing the pairing list of the dongle (Reset)	25
Specifications	26

Welcome

Stay agile, achieve more

Cut through the noise and make your presence felt with a headset that keeps you focused in open offices, open study environments, or on-the-go.

Get an immersive sound experience with the discreet boom arm for excellent speech intelligibility and use ANC in noisy situations to stay focused.

The soft, on-ear wearing style creates all-day comfort while the modern dual-foldable design gives you a handy and stylish look.

Make the most of your working or study day with a headset that adapts to your life and boosts your efficiency.

Key benefits & features

Stay focused anytime, anywhere with ANC

Four ANC microphones reduce background noise for a more immersive sound experience, together with plush ear pads for enhanced sound isolation.

Flexible connectivity

Enjoy multi-point connectivity that lets you connect to two devices simultaneously, via Bluetooth® or the USB-A dongle.

Up to 46 hours battery life

Enjoy up to 46 hours of playback and up to 41 hours of voice calls (24 hours when ANC is activated).

Ensure superior sound with a UC optimized solution

Enjoy efficient voice or video calls with a headset certified for Microsoft Teams and Zoom and optimized for UC.

Smart discreet boom arm

The small discreet, foldable boom arm and two advanced microphones ensure clearer voice pickup and are optimized for life on-the-go.

Enjoy comfort and convenience

Soft, on-ear wearing style for all-day comfort. Ear cups rotate and the dual-foldable design fits neatly into the handy carry case that provides maximum protection.

EPOS Audio Technology

EPOS engineered audio delivers clarity, resolution, and precision.



For safety instructions, consult the Safety Guide.



A list of accessories can be found on the product page at www.eposaudio.com/c50


Trademarks

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by DSEA A/S is under license. USB Type-C® and USB-C® are trademarks of USB Implementers Forum.

Qualcomm aptX is a product of Qualcomm Technologies International, Ltd. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries, used with permission. aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries, used with permission.


All other trademarks are the property of their respective owners.

Package contents




Product overview

Overview of the headset



Overview of the headset LED indications



^{*}Once the headset is successfully connected, the LED goes off.

Overview of the headset buttons

Power & Mute button Press Function		Page	
	2s	Turns the headset on / off	10
		Mutes / unmutes the microphone	12
		Cancels pairing (Pairing mode)	7
	_(\)	Pairs the headset with a Bluetooth device	7
	4s	Clears pairing list (Pairing mode): Press Power & Multifunction button	25


Hook button	Press	Function	Page
		Initiates a call	14
		Accepts / ends a call	14
		2 calls: Answers incoming & ends active call	16
		2 calls: Ends active & unholds paused call	16
		Invokes Microsoft Teams	17
	2x	Puts an active call on hold (pause) / unholds call	14
		Redials the last number	15
		2 calls: Answers incoming & puts active call on hold	16
		2 calls: Toggles between two calls	16
	(Activates voice assistant	15
	1s	Rejects a call	14

Multifunction button	Press	Function	Page
		Starts / pauses audio playback	
	2x	Skips to the next trackPress and hold: Fast-forwards the track*	18
	3x	 Skips to the previous track Press and hold: Rewinds the track* 	
		Decreases the volume (press or press and hold)	
		Increases the volume (press or press and hold)	11


 $[\]ensuremath{^{*}}$ These functions are not supported by all connected Bluetooth devices.

Settings button	tings button Press Function		Page
		Turns TalkThrough on/off (ANC turned on)	13
	1s	Requests remaining battery power	19
	2x	Turns ANC on / off	12
	4s	Enables/disables voice prompts	21

Overview of the dongle




Overview of the dongle LED indications



Overview of the dongle button

Link button	Press	Function	Page
	3s	Pairs the dongle with the headset	7
		Reconnects the headset	21
	2x	Disconnects the headset	21

Overview of the icons



Getting started

Pairing the headset with Bluetooth® devices



CAUTION

Danger of malfunction!

The transmitted radio waves of mobile devices can impair the operation of sensitive and unprotected devices.

Only use Bluetooth where it is permitted.

The headset complies with the Bluetooth 5.0 standard. Bluetooth devices need to support the "Hands-Free Profile" (HFP), the "Headset Profile" (HSP), "Audio Video Remote Control Profile" (AVRCP) or the "Advanced Audio Distribution Profile" (A2DP).




To transmit data via Bluetooth, you first have to pair your headset to a wireless device. The delivered dongle is already paired with the headset.

The headset can save up to eight paired devices. If you pair the headset with a ninth device, the device with the oldest activity in the pairing list will be overwritten. If you want to re-establish a connection with this device, you have to pair it again.

The headset can be connected to two of the paired devices at the same time. You can only connect another device by disconnecting one of the already connected devices.


Connecting the headset via the dongle



To connect the headset wirelessly with a computer, use the BTD 800 USB dongle.

The dongle and the headset are already paired.

- > Turn the headset on (see page 10).
- Plug the dongle into the USB port of your computer.



The dongle LED flashes blue while searching and switches to dimmed blue when connected successfully to the headset.

If Microsoft Teams is invoked: The dongle connects to Teams and lights up purple instead of blue.


The dongle shows Teams notifications (see page 17).



To manually pair the headset and the dongle, activate the pairing mode for both:

Press and hold the headset's Power button and the dongle's button until the LEDs alternately flashes blue and red. Once the dongle and the headset are connected, the dongle lights up dimmed blue.

Pairing the headset via Bluetooth with a mobile device



 Press and hold the Power button until the LED flashes blue and red.
 The headset is in pairing mode.



▶ Enable Bluetooth on your mobile device and start the search for Bluetooth devices – see instruction manual of your mobile device.



Select "EPOS C50" to establish a Bluetooth connection to the headset.




The LED flashes 2 times blue as soon as the headset finds a device to connect to. The LED turns off.



To cancel pairing:

> Press the Power button.

Using the USB cable



Connect the supplied USB cable to the USB socket of the headset and a USB socket of your computer.

Installing the EPOS Connect software




The free EPOS Connect software allows you to configure and update your headset and offers additional settings.

- Download the software from www.eposaudio.com/connect.
- ▶ Install the software.You need administrator rights on your computer.

To make calls via the computer:

▶ Install a softphone / VoIP software application.

Changing Audio settings for the headset - Microsoft® Windows



Windows usually changes the Audio settings automatically if you connect a new headset.

If the headset is connected but you hear no sound:

- > Select under output C50 as speaker.
- > Select under input C50 as microphone.

Using the headset




CAUTION

Hearing damage due to high volumes!


Listening at high volume levels for long periods can lead to permanent hearing defects.

- > Set the volume to a low level before putting on the headset.
- Do not continuously expose yourself to high volumes.

Turning the headset on and connecting it




Press the Power button for 2 seconds. The headset turns on. The LED flashes blue shortly. The headset automatically tries to connect to available paired Bluetooth devices.



The LED flashes 2 times blue as soon as the headset finds a device to connect to. The LED turns off.

If the LED flashes red, no paired device has been found.


Turning the headset off



- Press the Power button for 2 seconds. The LED flashes red 3 times and turns off. All volume settings are saved automatically when the headset is turned off.
- Charge the headset (see page 19).

> Store the headset (see page 20).


Adjusting and wearing the headset



For good sound quality and best possible wearing comfort, adjust the headset.


- ▶ Put the headset on so that the headband runs over the top of your head and the side with the R marking rests on your right ear.
- > Adjust the headset so that
 - · your ears are comfortably covered by the ear pads,
 - · you feel even, gentle pressure around your ears,
 - a snug fit of the headband on the head is ensured.

Adjusting the volume



You can adjust three independent volume settings for the headset:

- 1. Call volume: during an active call
- 2. Audio volume: during audio streaming
- 3. Volume for ring tone, tones and voice prompts: in idle mode no active call or audio streaming




> Press the Multifunction button to increase or decrease the volume

You hear a beep or double beep for maximum or minimum volume.


Alternatively you can adjust the volume on your connected device.


Adjusting the headset's microphone volume for softphones



- ▷ Initiate a call on your connected device to someone who will help you find the correct volume setting for your microphone.
- ▷ Change the microphone volume in your softphone application and/or in your PC audio application.

Muting the microphone











Using Active Noise Cancellation (ANC)

This headset provides attenuation of ambient noise using Active Noise Cancellation (ANC) technology. Special microphones optimize speech and reduce background noise.




If you are in a noisy environment but would like to have your own quiet space, you can use the headset itself, disconnected from any device, and simply benefit from ANC. You can activate ANC if the battery is sufficiently charged and if the headset is turned on.



Turning TalkThrough on / off


TalkThrough allows you to communicate with your colleagues without having to remove the headset, even when ANC is turned on. Audio playback will be paused or muted.



Making calls using the headset

The following functions depend on the connected device.

Making a call




- $\,\triangleright\,$ Initiate the call on your connected device.
 - OR
- Press the Hook button to initiate a call via your softphone.

If your call is not automatically transferred to the headset:


Search this function in the instruction manual of your connected device.

Accepting / rejecting / ending a call


When you receive a call, you hear a ring tone and the LED flashes blue.




Accept / hold a call



Reject / end a call




Redialing



Using the voice assistant / voice dial

The last connected Bluetooth device will be used for voice assistant or voice dial.



Managing multiple calls




You can use the Headset with up to two connected Bluetooth devices.


Two calls can be managed simultaneously.

If you receive a call during an active call, a knock on tone will be played.


Accept / reject second call



Toggle between calls / end active call




Using headset and dongle with Microsoft® Teams



To use Microsoft Teams with the headset:

▶ Plug the dongle into the USB port of your computer – see page 7.

If Microsoft Teams is already running, the blue LED changes to purple automatically.



To invoke Microsoft® Teams and check notifications:

Start Microsoft Teams on your computer.
The dongle connects to Microsoft Teams and the LED blue LED changes to purple.



The LED pulses purple to indicate:

- · Meeting Join Notification
- · Voice Mail Notification
- Missed Call Notification


To check these Notifications on your screen:

Press the Hook button.

Listening to audio using the headset

You can listen to audio via a connected device. The following functions depend on the connected device.

▶ Play the media on your connected Bluetooth device. The LED on the dongle lights up blue.




i

If you receive and accept a call, audio playback is paused and restarts after the call – if supported by the connected device.

Additional functions

Charging the headset battery

Connect the supplied USB cable to the USB socket of the headset and a USB socket of your computer.



The battery is being charged. The LED lights up depending on the battery status of the headset and turns off when the battery is fully charged.

LED	Battery status
•	100% - Battery fully charged
	more than 60%
	more than 20%
*	less than 20%


To end charging:

Disconnect the USB cable from the headset.




When the battery is flat, the headset turns off automatically.

Verifying remaining battery power



Some mobile devices indicate the battery status of the headset.



You can retrieve information on the remaining battery power at any time – except while you are in a call:

Press the Settings button for 1 second. The LED flashes shortly and a voice prompt is announced.




When the battery power drops below 20%, the LED flashes red and "Recharge headset" is announced several times.

LED	Remaining battery power
	more than 60%
	more than 20%
*	less than 20% - automatic voice prompt

Storing and transporting the headset

To avoid nicks or scratches on the headset:




- > Fold the ear cups inwards towards the headband.
- > Store the headset in the case when not in use or when carrying it around. Keep it in a clean and dry environment.

If you do not use the headset for extended periods of time:

▶ Charge the built-in rechargeable battery every 3 months for about 1 hour.


If you leave the Bluetooth range

The range between headset and Bluetooth device is device dependent. The transmission range largely depends on environmental conditions such as wall thickness, wall composition etc. With a free line of sight, the transmission range of most Bluetooth devices is up to 25 meters.



If the audio quality deteriorates e. g. during a call or the link breaks down completely:


> Re-enter the radio range of the Bluetooth device.



If you re-enter the Bluetooth transmission range within 5 minutes, the connection is re-established.


After more than 5 minutes the connection breaks down completely and you have to manually re-establish the connection:

▶ Tap the Multifunction button.



Reconnecting / disconnecting Bluetooth


Reconnecting Bluetooth



□ Tap the headset's Multifunction button or the dongle's button.


The headset flashes 2 times blue as soon as the headset finds a device to connect to. The dongle flashes blue and lights up dimmed blue.

Disconnecting Bluetooth



Double tap the dongle's button.
 Bluetooth will be disconnected. The LED flashes 3 times

Enabling / disabling voice prompts



In idle mode (no active call or audio playback):


Press and hold the Settings button until the headset announces a voice prompt for on or off.



If the voice prompts are deactivated you hear tones instead.

Maintaining the products and updating the firmware

Cleaning the products



CAUTION


Liquids can damage the electronics of the product!


Liquids entering the housing of the device can cause a short circuit and damage the electronics.


- Do not use any cleansing agents or solvents.
- > Only use a dry cloth to clean the product.

Replacing the ear pads

For hygienic reasons, you should replace the ear pads from time to time. Spare ear pads are available from your EPOS partner.








Insert the fixation band – stitched line facing to bottom – in the space on the ear cup.

Updating the firmware of the products

To update the installed firmware:

▶ Install the free of charge EPOS Connect software (see page 9).


Updating the firmware of the headset



 Connect the USB cable to your headset and your computer.
 The LED lights up.



Updating the firmware of the dongle



- ▶ Plug the dongle into the USB port of your computer. The LED lights up.
- Start EPOS Connect.


 If there is a new firmware available the software will guide you through the update process.

If a problem occurs ...


Problem	Possible cause	Solution	Page
Headset cannot be turned on	Rechargeable battery empty		19
Active Noise Cancellation	Rechargeable battery empty		19
(ANC) cannot be turned on	Headset turned off	Turn the headset on.Double tap the Settings button.	10
No audio signal or drop outs	Headset not paired with a Bluetooth device	▶ Pair the headset.	7
	Volume adjusted too low	▷ Increase the volume.	11
	Headset turned off		10
	Computer: Headset not selected as audio device	Change the Audio settings of your computer.	9
Headset cannot be connected via Bluetooth	Headset not paired	Pair the headset with a Bluetooth device (max. 20 cm distance while pairing between devices).	7
		Check if your Bluetooth device supports the HF or HS profile.	-
	Bluetooth at mobile device turned off		-
	Dongle not plugged in	Plug the dongle into the USB port of your computer.	7
Microsoft Teams does not	Dongle or Microsoft Teams	□ Unplug and plug the dongle again.	-
work: LED blue instead of purple	disturbed		-
Beeps instead of voice prompts	Voice prompts disabled		21
Headset or dongle does	Software or hardware problems	□ Turn the headset off and on again.	10
not react to any button press		□ Unplug and plug in the dongle again.	7
		Clear the pairing list of the headset.	25
		▷ Clear the pairing list of the dongle.	25

If a problem occurs that is not listed in the above table or if the problem cannot be solved with the proposed solutions, please contact your local EPOS partner for assistance. To find the EPOS partner in your country, search at www.eposaudio.com.

Clearing the pairing list of the headset (Reset)




▶ Press and hold the Power button until the LED flashes blue and red.




 Simultaneously press and hold the Multifunction button and the Power button for 4 seconds.
 The LED flashes blue 3 times. The pairing list is cleared.
 The headset searches for Bluetooth devices to pair with - see page 7.

Clearing the pairing list of the dongle (Reset)



- ▶ Plug the dongle into the USB port of your computer.
- Press and hold the button until the LED flashes blue and red.



Double press the dongle's button.

The LED flashes purple 3 times. The pairing list is cleared. The dongle searches for Bluetooth devices to pair with – see page 7.

Specifications

Headset - General

Wearing style On-ear, double-sided headband

Dimensions (W x H x D) 163 x 181 x 75 mm

Weight 229 g

Transducer principle Dynamic, closed

Connectivity: Multi-point connectivity: dual

Bluetooth 5.0 USB-A dongle

USB-A to USB-C® charging cable

Headset connector USB-C® plug

Supported Bluetooth profiles Hands-Free Profile (HFP), Headset Profile (HSP), Audio Video Remote Control

Profile (AVRCP), Advanced Audio Distribution Profile (A2DP)

Supported codecs SBC, aptX™

Rechargeable battery (built-in) Lithium Polymer / 3.7 V DC / 600 mAh

Charging time 3 hours 40 minutes

Battery time Listening time: up to 46 hours (ANC off) / up to 24 hours (ANC on)

Talking time:

up to 41 hours (ANC off) / up to 24 hours (ANC on)

Standby time Up to 81 days

Range Up to 25 m (device dependent)

Headset - Audio

Speaker frequency response 20 to 20,000 Hz

Sound pressure Limited by EPOS ActiveGard®: max. 108 dB

Total harmonic distortion (THD) O.3% @1 kHz, OdB FS

Noise cancellation Hybrid ANC technology with 4 microphones

Microphone type Noise-cancelling

Microphone frequency response 100 to 10,000 Hz

BTD 800 USB dongle

Dimensions (W x H x D) 22 x 16 x 6 mm

Weight 2 g

Connector USB-A plug

EPOS | SENNHEISER



DSEA A/S

Kongebakken 9, DK-2765 Smørum, Denmark www.eposaudio.com